

How do I download my images from my digital camera?

There are two methods used to download images to your computer. You can use:

1) a USB or Firewire cable or 2) a Card Adapter which reads the memory



Using a USB or Firewire Cable:

Connect to both the camera and computer. This usually has software that you install that will recognize the digital camera and will automatically detect the images.

Using a Memory Card Adapter:

Remove the memory from the camera, insert into the adapter. The adapter fits into the PCMCIA reader on the side of the laptop. Desktop computers need memory card reader not the adapter.